

Countywide Work Practices

Specific Activity	Work Practice
Bulk Material Hauling off-site onto paved public road-way	Load all trucks such that the freeboard is not less than three inches; and prevent spillage or loss of bulk material from holes or other openings in the conveyance; cover all haul trucks (empty or full) with a tarp or other suitable anchored material.
Bulk Material Hauling on-site (within work site)	Limit the vehicle speed to less than 15 mph; or apply water to the top of the load; or cover the hauled material.
Spillage, carry-out, erosion, and/or trackout	Install a suitable trackout control device from all work sites with a disturbed area of 5 acres or more and from all work sites where 100 cubic yards of bulk materials are hauled on/or off site per day.
Cleanup spillage, carry-out, erosion and/or trackout on the following schedule:	Immediately, when spillage, carry-out, and/or trackout extend a cumulative distance of 50 feet or more; or at the end of the work day.
Unpaved easements, right-of-way, and access roads	Inside PM10 nonattainment area, restrict vehicular speeds to 15 mph.
Open storage piles	During stacking, loading and unloading operations, apply water as necessary and/or construct and maintain wind barriers, storage silos, or a three-sided enclosure to surround pile and whole height is equal to the pile.
Weed abatement by discing or blading	Apply water before and during weed abatement.
Other work activities as provided by the registrant	Specific work practices that are adequate to address nuisance issues at the earth moving activity site.